

Care and cleaning

Routine maintenance

Dusting

Surface dust may be removed with a feather duster or clean dry cloth.

Spot cleaning

For spills and stains, simply wipe the fabric with a sponge and lukewarm water. If marks are still visible, add a little mild detergent and gently dry with a clean cloth.

The information and advice included in this brochure has been prepared with care. However, we are unable to accept responsibility for the results of or any damage caused during operation.

As with all textiles, Luxaflex® fabrics are subject to some variations. Slight wrinkling, puckering or bowing is inherent in textile products and should be considered normal, acceptable quality. Precautions should be taken to reduce exposure to harsh environmental elements, such as salt air. Continuous exposure through open windows and doors will accelerate the fabric deterioration. Additionally, there will be slight differences in pattern alignment from the fabric on the rails to the fabric of the shade, which do not detract from the product's appeal. Variations in colour and/or pattern irregularities are unique characteristics that contribute to the classic beauty of a shade.

© Copyright 2017 Hunter Douglas Limited [ABN 98 009 675 709]. © Registered Trade Marks of Hunter Douglas Limited. 18.017.036 C14375_08.2017

luxaflex.com.au



Vertical Blinds



Welcome to the Luxaflex lifestyle

Thank you for purchasing Luxaflex® Vertical Blinds. With proper operation and care your new blinds will provide years of beauty and performance. Please review this instruction booklet thoroughly for operation and care information.

Operation

Chain and Cord operation

To open the blades, pull the chain until the blades are in the desired position. To pull the blades to one end, pull the cord until all blades are stacked together.



Traversing Wand operation

To open or close the blind, turn the wand until the slats are tilted to the desired position. To traverse the blind, pull the wand until the slats are stacked to the desired position.



Monocommand 180° operation

Pull on the continuous beaded cord to tilt or move the blades of the blind.

